Quick Installation Guide(For Android Mobile Phone)

- 1: System Requirements: Android 2.3 or above.
- 2: e-View P2P Software Installation.



Insert the CD in your CD drive of your computer Open the CD file, find out the Android P2P software :"e-View", copy it to your mobile phone and run it, until installed successfully.



- **3: Connected the camera to e-View Software.**
- A: First connected your mobile phone' wifi. (Note: The phone and the camera must in the same LAN.)
- B: Second run the e-View software.
- C: After the e-View been runing, you will find "Please tap here to add new camera" Please click here and add cameras.



D: Add the camera to the e-View Software.

There are two way to add the camera to the e-View Software.

(1) Manually : Please click "Search" Button, then you will get a list of the camera in the same LAN as your phone. Choose the camera which you want view.

sign the user and passward, finally click "OK", the camera have been added in the e-View software.

Add Camera		Add Camera		e-View	
Camera IPCamera	ne C. IP	U-000048-HFPNF	-	IPCamera ID 08J-000051-2EH0U Blates of fire	
Scan ID Search		Scan ID Search	-	IPCAM ID: 08J-000114-2FXNF Status of Free	
User admin	User ad	min		IPCamera ID: 080-000048-HPPN/ Status connecting	
Passwo	Passwo	_			

(2) Automatically (Scanning bar code): Press the "Scan ID" button, you need to install the "barcode scanner first ,after installed successfully ,in the button of the camera there is a label with the "2-dimensional bar code", then use your mobile phone scanner to scan the bar code, it will show the ID, then press "ok" you will view the monitoring vedio.

Touch the screen, the control buttons will show. As below pictures



