

# How to set the Wifi

You need to connect the ip camera with your computer via network cable the first time and then set the wifi .

The screenshot shows the IP Camera Client software interface. At the top, there is a toolbar with several icons, including a gear icon labeled 'Config'. A red arrow points to this gear icon. Below the toolbar is a camera feed window showing a room with a wall-mounted light fixture and some decorations. The text 'click here' is overlaid in yellow on the camera feed. To the left of the camera feed is a sidebar with a list of camera sources, including 'westmie', '192.168.1.88:80', 'Channel 01', 'Current Screen', and '1-192.168.1.88:80-C01'. Below the camera feed is a 'PTZ' control panel with various directional and zoom buttons. At the bottom of the interface is a log table with the following data:

	Source	Time	
●	192.168.1.88:80-C1	15-05-01 23:40:00	Connect Success!
■	192.168.1.88:80-C1	15-05-01 23:36:08	Connect Failure!




# IP CAMERA



- Device Management
- Group Management
- Parameter settings
- Record Management
- Linkage Alarm
- User Management
- Other Settings

westmile  
- 192.168.1.88:80  
- Channel 01

- Color
- Video
- Audio
- OSD
- Network
- MD
- Alarm In
- PTZ
- System
- Wifi



Brightness:  0  
Saturation:  0  
Contrast:  0

Default

Flip  Mirror

Scene: Auto

Infrared: Auto

double click here



- Device Management
- Group Management
- Parameter settings
- Record Management
- Linkage Alarm
- User Management
- Other Settings

westmile  
192.168.1.88:80  
Channel 01

- Color
- Video
- Audio
- OSD
- Network
- MD
- Alarm In
- PTZ
- System
- Wifi



Brightness: 50  
Saturation: 120

RSSI	SSID	WPA A...	Securt...	Wifi M...	Channel
73	Tenda_4F1468	AES	WPA...	Infra...	9
42	ChinaNet-CO	TKIP	WPA...	Infra...	1
42	iTV-CO	TKIP	WPA...	Infra...	1
2	MERCURY	AES	WPA...	Infra...	11

Wifi configuration window with fields for SSID, Wifi Mode, Security Mode, WPA Algorithm, Key, and Re-type Key. Includes 'Enable Wifi' checkbox and 'Check Wifi' button.

choosing your wifi router

Input wifi router password

# setting wifi via IE

1) Connecting the ip camera to your computer  
2) input the ip address  
3) Download the active X (first time)  
4) User name: admin  
Password: admin

**IP CAMERA**

Welcome! Select what you want to do:  
[PC view](#)  
[Mobile view](#)  
[Setup software \(first time\)](#)

Language: [Chinese](#) [English](#)

**IP CAMERA**

Monitor Settings

Media  
Network  
Network  
Network  
Wireless  
Data  
Platform  
ONVIF  
P2P  
Alarm  
Advanced  
System

Wireless

Enable Wireless:  On  Off

SSID:

Security mode: WPA-PSK

WPA Algorithm: AES

Key:

Re-type key:

Check Wireless Setup:

7)

8)

3)  On

4)

5) choosing your wifi router



6) input the password for your wifi router

WiFi Scanner - Windows Internet Explorer

http://192.168.1.88/web/scan.html

Add	RSSI	SSID	Encrypt	Auth	Network Type	Channel
Join	57	Tenda_1...	AES	WPA-PSK	Intra	9
Join	37	ChinaNet-CO...	TKIP	WPA-PSK	Intra	1
Join	31	ITV-CO...	TKIP	WPA-PSK	Intra	1

# How to check the P2P



Support Iphone/Ipad/Android

中国移动 5:22 PM  
Camhi 1 个结果



CamHi  
Qi Zhao



精品推荐 排行榜 探索 搜索 更新

中国移动 5:20 PM  
Camera Add Camera Done

Name	Camera
Account	admin
UID	Camera UID
PassWord	Camera PassWord

WIFI Search >

WIFI Smart Set >

Camera Photo video About